

HSE Alert 08 in 2019

Immediate stop use: Miller MightEvac – MightyLite self retracting lifeline end users

Date of issue: 9 September 2019

Background

We have been informed by Honeywell Miller of potentially non-conforming brake components in certain models of Miller MightEvac and MightyLite Self-Retracting Lifelines (SRLs) ranges manufactured within a specific timeframe. While there have been NO reported incidents due to this nonconformity, continued use of the product could result in serious injury or death.



Instruction

Products included in this notice must be removed from use.

This notice only affects the models listed in the table on page 3 of this alert, with identified manufacturing dates or re-certification dates between 27 October 2016 and 6 October 2018. Models outside of this date range, including new units, are not affected by this notice.

- Step 1: Look for model number on the product label and the date of manufacture (see Figure 1 below).
- Step 2: If the model number on the label is on the list on Table 1 AND the manufacture date is between 27 October 2016 and 6 October 2018, then remove this product from service immediately.
- Step 3: If the unit has been re-certified or repaired (See Figure 2) between 27 October 2016 and 6 October 2018, then remove this product from service immediately.
- Step 4: Once you have identified affected units, go to <https://industrialsafety.honeywell.com/content/his/us/en/stopuse.html> to submit a request for returning your unit to Honeywell for repair.

Affected models of Miller MightEvac and MightyLite Self-Retracting Lifelines (SRLs) will require replacement of the brake component at Honeywell's repair centre. Replacement of the brake component will be free of charge and at no additional cost to us. Honeywell will provide more details on the return and replacement process. For questions about how to determine whether your product is affected by this notice, please contact Honeywell directly on 1-800-873-5242 (option 5) or email hsprepairs@honeywell.com



Figure 1: Variable Label

Each unit contains a variable label located on the front or back of the unit. The specific model and date of the manufacturer is printed on the variable label.



Figure 2: Recertification label example

A recertified unit has a recertification date label containing the original date of manufacture along with the date of recertification

| | |
|-------------------------------|--|
| For more information contact: | hsprepairs@honeywell.com |
| Approved by: | Alec Ferguson, HSE Senior Manager |

| MightyLite Self-Retracting Lifelines | | | |
|---|------------------|-------------------|------------------|
| RL100BG/100FT | RL30P-Z7/30FT | RL65G-Z7LEK/65FT | 1002828 |
| RL100G/100FT-USS | RL30SS-Z7/30FT | RL65SS-S/65FT | 1004574 |
| RL100G-Z7/100FT | RL40K-Z7/40FT | RL65SS-Z7/65FT | 1004575 |
| RL100SS-S/100FT | RL40MG/40M-AUS | RL80K-Z7/80FT | 1004594 |
| RL100SS-Z7/100FT | RL50BG/50FT | 140059/30FT | 1004595 |
| RL120G-Z7/120FT | RL50BG-Z7/50FT | 150077/30FT | 1002828C |
| RL130G/130FT-POR | RL50BSS-Z7/50FT | 170016/57FT6IN | 1004571C |
| RL130G-Z7/130FT | RL50G-Z7/50FT | 170053/LW6771 | 1004572C |
| RL130SS-Z7/130FT | RL50G-Z7LE/50FT | 20A901 | 1004574C |
| RL140G/140FT-SPA | RL50G-Z7LEK/50FT | 2JFC9 | 1004574C |
| RL175G-Z7/175FT | RL50P-S/50FT | 2JFD3 | 1004575C |
| RL175SS/175FT | RL50P-Z7/50FT | 36WA16 | 1004593C |
| RL175SS-S/175FT-POR | RL50SS-S/50FT | 45J014 | 1004594C |
| RL175SS-Z7/175FT | RL50SS-Z7/50FT | 45J015 | 1004595C |
| RL30G-Z7/30FT | RL65G-Z7/65FT | 45J018 | |
| RL30MG/30M-AUS | RL65G-Z7LE/65FT | 45J019 | |
| MightEvac Self-Retracting Lifelines with Retrieval | | | |
| MR100GB/100FT-POR | MR130G-Z7/130FT | MR50G-Z7/50FT | MR80K-Z7/80FT |
| MR100GB-Z7/100FT | MR130SB-Z7/130FT | MR50S/50FT | 120032/100FT |
| MR100GCM-Z7/100FT | MR130SX-Z7/130FT | MR50SB-S-Z/50FT | 1XEU2 |
| MR100GC-Z7/100FT | MR130S-Z7/130FT | MR50SB-Z7/50FT | 20A766 |
| MR100GX/100FT | MR15MGB/15M-AUS | MR50SCN/50FT | 20A773 |
| MR100GX-Z7/100FT | MR30MGB/30M-AUS | MR50SC-S/50FT | 36WA24 |
| MR100G-Z7/100FT | MR40K/40FT | MR50SC-Z7/50FT | 45JK01 |
| MR100SB-S/100FT | MR40KB-Z7/40FT | MR50SS-S-Z7/50FT | 5YH35 |
| MR100SB-S-Z/100FT | MR40KC/40FT | MR50SX/50FT | 1005160 |
| MR100SB-Z7/100FT | MR40KC-Z7/40FT | MR50SXM/50FT | 1005161 |
| MR100SC-Z7/100FT | MR40KX/40FT | MR50SXM-Z7/50FT | 1014370 |
| MR100SX/100FT | MR40K-Z7/40FT | MR50S-Z7/50FT | 1005149-A |
| MR100S-Z7/100FT | MR50GB/50FT-POR | MR80KB/80FT | 1014390-A |
| MR130GB-Z7/130FT | MR50GB-CE/50FT | MR80KB-Z7/80FT | |
| MR130GC-Z7/130FT | MR50GB-Z7/50FT | MR80KC/80FT | |
| MR130GX-Z7/130FT | MR50GX-Z7/50FT | MR80KC-Z7/80FT | |
| RoofStrider MightyLite Kits | | | |
| RM50G/50FT | SRM50G/50FT | SRM50P-Z7/50FT C | SRM65G-Z7/65FT C |
| SRM30G/30FT | SRM50G-Z7/50FT C | SRM50SS-Z7/50FT C | |
| SRM30G-Z7/30FT C | SRM50P/50FT | SRM65G/65FT | |
| Repair Parts | | | |
| 6139853/ | 6139872/ | 7286980/1 | |